



Pat. No's 6,435,460 D437,864



Carefully lay brake over on it's back.




Unfold stand next to brake.



Place legs into channels as shown. Insert faspins.




Place top legs into channels as shown. Insert faspins.




With firm grip on brake, slowly lift until upright.



Remove faspin from each leg brace assembly.



Align holes in brace with holes in legs. Insert faspins.



Stand squarely on foot board while bending. Use two people to make bends when necessary.